

### PART 3 EXECUTION

#### 3.01 INSPECTION

- A. All supporting surfaces shall be structurally sound, solid, stable, level, plumb and true to a tolerance in plane of 1/4" in 10 feet (6 mm in 3 m) for floors. Cracks and holes must be filled with a fast-setting cement-based polymer modified patching compound or equivalent.
- B. Harbinger Signature Acoustic Click can be installed on existing firm floors (Linoleum, PVC), but all textile floors must be removed. Substrate must be properly primed and leveled according to National Floor Covering Association specification guide. Refer to [www.us.uzin.com](http://www.us.uzin.com) for primer and leveling products or call Uzin North America 1-866-505-4810.
- C. Failure to call attention to defects or imperfections will be construed as acceptance and approval of the subfloor. Installation indicates acceptance of substrates with regard to conditions existing at the time of installation.

#### 3.02 PREPARATION

- A. Smooth concrete surfaces, removing rough areas, projections, ridges, and bumps, and filling low spots, control or construction joints, and other defects as recommended by the flooring manufacturer.
- B. Vacuum or broom-clean surfaces to be covered immediately before the application of flooring. Make subfloor free from dust, dirt, grease, and all foreign materials.

#### 3.03 INSTALLATION

- A. Install flooring in strict accordance with the latest edition of "Harbinger Signature Acoustic Click installation guide".
- B. Do not proceed with floor surface installation until all applicable site work, including substrate preparation, painting, equipment installation and other relevant work by trades affecting the installation area has been completed.
- C. Install flooring with tools and procedures in strict accordance with the manufacturer's written instructions.

#### 3.04 CLEANING AND PROTECTION

- A. Cleaning: Perform the cleaning operations in accordance to the latest edition of "Harbinger Maintenance Guide".
- B. Protection: Protect the installed flooring against damage from rolling loads, other trades, or the placement of fixtures and furnishings. Refer to "Harbinger Signature Acoustic Click Installation Guide" and "Harbinger Maintenance Guide".

### END OF SECTION

***These Architectural Specification Guidelines are intended for use by design and specification professionals as a template aid to specify and describe Harbinger products as part of the written Specifications component of Construction Contract Documents.***

***The data contained in this document is accurate as of the date of publication. Updates and revisions may have been made since this date. If verification is needed that this data is still current, please contact Harbinger at 1-866-646-6519.***